



Input: one-phase / three-phase power



Connect Live to R and Neutral to S for single phase input supply
Connections U/T1, V/T2, W/T3 go to the motor

Connect 3 phase input supply to L1/R, L2/S, L3/T
Connections U/T1, V/T2, W/T3 go to the motor



Instructions for Remote Setup (Remote On/Off and Speed Variation)

- For remote stop and start connect between DCM and MI1 (FWD) and MI2 (REV) (DCM is your common)
- For remote Potentiometer connect the pot to +10V, AVI and ACM (common).
- Set **00.20** to 2 (Remote Potentiometer)
- Set **00.21** to 1 (Remote ON/OFF setting)
- Set **02.00** to 1 or 2 (2-wire operation control)

Pr.02-00	External Terminal Control Circuits
Setting value: 1 Two-wire operation control FWD / STOP REV / STOP	<p>MI1 "OPEN": STOP "CLOSE": FWD</p> <p>MI2 "OPEN": STOP "CLOSE": REV</p> <p>DCM</p> <p>MS300</p>
Setting value: 2 Two-wire operation control RUN / STOP FWD / REV	<p>MI1 "OPEN": STOP "CLOSE": RUN</p> <p>MI2 "OPEN": FWD "CLOSE": REV</p> <p>DCM</p> <p>MS300</p>

- Set **02.00** to 3 (3-wire operation control)

Setting value: 3 Three-wire operation control	<p>MI1 "CLOSE": RUN</p> <p>MI3 "OPEN": STOP</p> <p>MI2 REV/FWD: "OPEN": FWD "CLOSE": REV</p> <p>DCM</p> <p>MS300</p>
--	--

V/F curve set up Factory setting is General purpose

General purpose			Fan & Hydraulic			High starting torque		
	230V	400V		230V	400V		230V	400V
PR.	SETTING		PR.	SETTING		PR.	SETTING	
01-00	50	50	01-00	50	50	01-00	50	50
01-01	50	50	01-01	50	50	01-01	50	50
01-02	230	400	01-02	230	400	01-02	230	400
01-03	1.3	1.3	01-03	25	25	01-03	2.2	2.2
01-05			01-05			01-05		
01-04	10	20	01-04	50	100	01-04	23	46
01-06			01-06			01-06		
01-07	1.3	1.3	01-07	1.3	1.3	01-07	1.3	1.3
01-08	10	20	01-08	10	20	01-08	14	28



**QUICK SETUP INSTRUCTIONS
FOR VARIABLE SPEED DRIVE
1 PHASE TO 3 PHASE
AND
3 PHASE TO 3 PHASE**



VFD-MS300 Series



HAMILTON PH: 07 847 3374
CHRISTCHURCH PH: 03 666 3374
sales@rotatingmachinery.co.nz



AUCKLAND PH: 09 271 6063
info@brookmtl.co.nz

Important Notice

- Wiring and connection must be carried out by a registered electrician.
- Connection by an unqualified person voids the warranty.
- Please check the suitability of the motor before attempting to connect it to the device.
- Ensure the motor terminals are configured to suit supply from VSD, for 1ph supply VFD the motor must be connected in DELTA. For 3ph supply VFD please consult the motors name tag for 400V connection.




1. **Status Display** –Display the drives current status
2. **LED Display**—Indicates frequency, voltage, current, user defined units
3. **Potentiometer**—For local frequency control
4. **Run Key**— to start drive locally
5. **UP & DOWN Key**—Used to change numerical numbers, frequency, parameters
6. **Mode**—Change between different display mode
7. **STOP/RESET**— Stops AC drive operation and resets the drive after a fault has occurred
8. **ENTER** - Used to enter and save the parameters

FOR ADVANCED SET UP REFFER TO THE FULL MANUAL

Quick Setup for Variable Speed Drive

Turn on power to unit and follow as below:



- F60.0 will be displayed on the screen.
- Press the enter button.
- 00. will appear on the screen.
- Press enter again.
- 00.00 will appear on the screen.
- Use the up and down keys to change parameters selections to the desired one. Press "ENTER"
- You will now be able to change the parameter to the desired value or setting. Press enter. End will flash on your screen to indicate that your setting has been saved.
- Continue the above steps till all of your parameters have been set.
- Once all the parameters have been set press the "MODE" button till the F50.0 screen comes up again.

10-2 Descriptions of keypad functions

Displayed items	Descriptions
RUN ● FWD ● REV ● F60.0 ● STOP ● PLC	Displays the present frequency setting for the drive.
RUN ● FWD ● REV ● H500 ● STOP ● PLC	Displays the actual frequency output to the motor.
RUN ● FWD ● REV ● U 18 ● STOP ● PLC	Displays the user-defined output of a physical quantity. This example is for parameter Pr.00-04 = 30.
RUN ● FWD ● REV ● A 50 ● STOP ● PLC	Displays the load current.
RUN ● FWD ● REV ● Fwd ● STOP ● PLC	Forward command
RUN ● FWD ● REV ● Rev ● STOP ● PLC	Reverse command
RUN ● FWD ● REV ● c 20 ● STOP ● PLC	Displays the count value.
RUN ● FWD ● REV ● 0600 ● STOP ● PLC	Displays a parameter item.
RUN ● FWD ● REV ● 10 ● STOP ● PLC	Displays the content of a parameter value.
RUN ● FWD ● REV ● EF ● STOP ● PLC	Displays an external fault.
RUN ● FWD ● REV ● End ● STOP ● PLC	Displays the data that has been accepted and automatically stored in the internal memory.
RUN ● FWD ● REV ● Err ● STOP ● PLC	Displays the data set that is not accepted or has exceeded the value.

List of quick set parameters

- **00.02** All parameters are reset to factory settings for 50Hz, set to 9 (must be none after initial power up)
- **00.20** Source of master Frequency Command.
0 = UP/DOWN arrow (Factory setting)
2 = External analog input
3 = External UP/DOWN terminals
7 = Digital keypad potentiometer
- **00.21** Source of master Operation Command.
0 = Digital keypad (Factory setting)
1 = External terminals
- **01.00** Change to the maximum Frequency required
- **01.01** Change value to match Hz on motor name plate
- **01.02** Change to match voltage on motor name plate (Max Voltage output)
- **01.10** Upper limit Frequency
- **01.11** Lower limit Frequency
- **01.12** Acceleration time (factory setting 10sec)
- **01.13** Deceleration time (factory setting 10sec)
- **05.01** Set to Motor Name Plate Current
- **05.02** Set to Motor Name Plate kW
- **05.03** Set to Motor Name Plate Speed (rpm)
- **05.04** Set as the number of poles of the motor(3000rpm=2pole; 1500rpm=4pole; 1000rpm=6pole; 750rpm=8pole)
- **05-00** Auto tuning, option 1 Dynamic test for induction motor = 1 (note motor must be unloaded), Static test for induction motor = 2, after the parameter number is entered press MODE button to return to main screen showing F30.00 or F33.33, press the RUN button to start auto tune, these test should only be preformed after all the above data is entered.

See back page for remote control set up